
NETWORK MANAGER (HUMAN)
NETWORK MANAGEMENT STATION
302
SNMP MANAGER
304
TEXT-BASED INTERFACE
308
SNMP MANAGER
320
SNMP AGENT
310
CONFIGURATION DATA
306
ACCESS DEVICE
300
TEXT-BASED INTERFACE
318
SNMP MANAGER
330
SNMP AGENT
340
CONFIGURATION DATA
316
ACCESS DEVICE
324

Fig. 3